

Z-Wave Remote Control

- Include or exclude the Dimming Switch Module from the existing Z-Wave home control network with your primary controller.
- Refer to your primary controller instructions to process the inclusion / exclusion setup procedure.
- When prompted by your primary controller, tap the button.
 The primary controller should indicate that the action was successful. If the controller indicates the action was
- unsuccessful, please repeat the procedure.
 Once the Dimming Switch Module is part of the network, the same basic procedure is used to add the Dimming Switch Module to groups or scenes. Refer to the primary controller's instructions for details.

All On/All Off functions

Depending upon your primary controller, the Dimming Switch Module can be set to respond to ALL ON and ALL OFF commands up to four different ways. Some controllers may not be able to change the response from its default setting. Please refer to your controller's instructions for information on whether or not it supports the configuration function and if so, how to change this settings.

- The four possible responses are:
- It will respond to ALL ON and the ALL OFF commands (default).
 It will not respond to ALL ON and ALL OFF commands.
- It will respond to the ALL OFF command but will not respond to the ALL ON command.
- It will respond to the ALL ON command but will not respond to the ALL OFF command.

Restoring Factory Defaults

All Configuration Parameters can be restored to their factory default settings by using your primary controller to reset the device. (delete from the network)

5

TECHNICAL SPECIFICATIONS

| Rating input: | 120Vac |
|---|---|
| Input frequency: | 60Hz |
| RF frequency: | 908.42MHz (ZDS-110NA) |
| Max. range: | up to 25m (line of sight between the Wireless Controller and the closest Z-Wave receiver module.) |
| Double outlets: | Z-Wave controllable "Always On" pass through |
| Selectable switch: | DIMMER(Dimming/ON/OFF) or SWITCH(ON/OFF) mode |
| Max. output power of Z-Wave controlled: | DIMMER: Max Incandescent load 330W 2.75A SWITCH: a. Max Incandescent Load 330W 2.75A b. Max Resistive Load 500W 4.16A |
| Max. power of "Always On" pass through outlet: | Resistive load 1200W |
| Max. power in total for both Z-Wave Outlet and Always on Pass through outlet: | Resistive load 1400W |
| Connect ability: | DIMMER: Can only be connected to incandescent lamp Resistive load. |
| | SWITCH: Can be connected to incandescent lamp, Resistive load. |
| Over Temperature protection: | Detected internal temperature, and cut off output once OTP triggered. (Remark: Under over loading or temperature situation, it will fail to start up). |
| EMC: | Meet FCC15 Class C and RSS 210 issue 8. |
| Safety: | Meet standard UL244A edition third revision 2010-3-4 and CSA C22.2 No.14 1 th with revision date 2010-2-1 and UL1310 fifth date 2005-05-03. |
| Dimension (L x W x H): | 126X68X40mm |
| Weight: | 180g |
| Storage: | -10~60°C |
| Operation Temperature: | 0~40°C |
| Relative Humidity: | 5~95% |
| | Indoor use only |

Certifications

UL Listed:

This power unit is intended to be correctly orientated in a vertical or floor mount position.

FCC Information

FCC ID : ZGID9190A01

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including

interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
 Connect the equipment into an outlet on a circuit different
- from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for help.

7

IC information IC : 9548A-D9190A01 This device complies with Industry Cana

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and

(2) this device must accept any interference, including interference that may cause undesired operation of the device.

This device complies with RSS-310 of Industry Canada. Operation is subject to the condition that this device does not cause harmful interference.

There is no user serviceable parts in the Dimming Switch Module.

To avoid the risk of electric shock, the input prong comes with a round grounding plug. The switch module can only be plugged in to the power inlet with the grounding plug. Please contact a qualified electrician to replace the power inlet if it has no grounding inlet. Do not change the plug of Dimming switch module in any way.

RISK OF FIRE RISK OF ELECTRICAL SHOCK RISK OF BURNS

DID NOT QUALIFY FOR INSTRUMENT OF MEDICAL AND LIFE SUPPORT EQUIPMENT

Z-Wave Dimming Switch Module never got qualified certificate to supply power for medical instrument or any life support equipment. This Dimming Switch Module is complied with the Z-Wave standard of open site, line of sight transmission distances of up to 25m. Actual RF performance of Dimming Switch Module in a home was affected by the number of barrier/construction between the remote controller and the destination unit, in meanwhile, relies on the number of Z-Wave enabled devices installed in the control network.

8

3. Plug the Dimming Switch Module into a wall AC outlet.



- 4. Turn the light On/Off by pressing the button.
- (This is a toggle switch Press the button to turn the light On if it is in Off stage and vice versa)
- Adjust the brightness level by pressing and holding the button. Release the button when the desired level is attained. (This is also a toggle function Press and hold the button to dim-up the light and press and hold the button again to dimdown the light)



6. In the SWITCH mode, turn the light On/Off by pressing the button.

(This is a toggle switch - Press the button to turn the light On if it is in Off stage and vice versa)



WARRANTY

ONE-YEAR LIMITED WARRANTY: Remotec warrants this product to be free from defects in materials and workmanship under normal use and service for a period of one year from the original date of purchase from the distributor or dealer.

- REMOTEC shall not be liable for:
- Damages caused by defective devices for indirect, incidental, special, consequential or punitive damages, including, inter alia, loss of profits, savings, data, loss of benefits, claims by third parties and any property damage or personal injuries arising from or related to the use of the device.
- Service trips to provide instruction on product use.
- Shipping costs for replacement products.

This warranty is limited to the repair or replacement of this product only, if the purchase date cannot be substantiated, the warranty period will begin on the date of manufacture as indicated on this product. All warranty claims must be made to Remotec appointed distributors or dealers during the applicable warranty period. This warranty gives you specific legal right and you may also have other rights which vary in each country. Please contact Customer Service at:

Remotec Technology Limited E-mail: rtlsales@remotec.com.hk http://www.remotec.com.hk

F820-8011-0000